


Instruction Manual of InterHeat Thermostat Controller ITDC10

1. Specification


- 1) Input Voltage : 220V - 240V AC
- 2) Maximum Load : 9KW (37.5A)
- 3) Connection with Heater : 2 pcs. of 235V 1500W Heater per Output line x 3 lines = 9000W
(Refer to the Circuit Diagram on the page 2)
- 4) Temperature Range : -9°C ~ 99°C (Unit : 1°C)
- 5) Temperature Sensor : DS18B20 (Cable Length 10m)
- 6) Operating Environment : Temperature 1°C ~ 45°C, Humidity 85% and below
- 7) Size : 220mm(W) x 185mm(H) x 60mm(D)
- 8) Other Contents : a Remote Controller (RC-ITDC10) and Anchor Bolts.

- ★ Turn power off before beginning installation of Thermostat Controller and Carbon Fiber Heaters.
- ★ Installation and wiring must be done by a qualified electrician.
- ★ The ground wire must be connected.
- ★ Max. capacity (12.5A) per Output line must not be exceeded.
- ★ Solely designed for InterHeat Carbon Fiber Heaters. Do not connect with other products.


2. Temperature Setting



- 1) ON Temperature setting (Heaters will be turned on when Current Temperature is lower than ON Temp.)




- 2) OFF Temperature setting (Heaters will be turned off when Current Temperature reaches OFF Temp.)




3. Wire Connection

1) Open the cover with a screw driver




2) Connection Diagram

* Wire Connection of Thermostat Controller and Carbon Fiber Heaters



Min. Recommended Wire Specification : Input (8.0mm²) / Output 1, 2, 3 (2.5mm²)



4. Trouble Shooting



* Error code E1

E1 fault indicator light will be turned on in case of sensor malfunction or poor cable connection. When this light is on, find and fix the poorly connected point. Or replace either or both of the sensor and the cable.